
CHARCOAL CANISTER
CLOSURE VALVE
NO
NR
MAIN
HARNESS
NO
NR
MAIN
HARNESS
RY
GR
GW
RO
GN
GP
RB
B
GB
GK
R
WP
R
GK
BO
FUEL PRESSURE
SENSING
B
M
WP
FUEL PUMP
B
GB
FUEL GAUGE
GP
B
HIGH LEVEL
BRAKE LIGHT
GR
B
N/S INDICATOR
GP
B
N/S BRAKE
RB
B
N/S SIDE
RY
B
N/S FOG
GN
B
N/S REVERSE
RB
NO. PLATE
RB
NO. PLATE
GN
B
O/S REVERSE
RY
B
O/S FOG
RO
B
O/S SIDE
GP
B
O/S BRAKE
GW
B
O/S INDICATOR